

AMG C32/SLK32 Boost Kit Installation Instructions



1. Disconnect earth lead.
2. Remove radiator cooling fan.



3. Remove accessory belt



4. Remove upper idler pulley



5. Assemble the KLEEMANN idler as shown with provided bearing and circlip.



6. Install KLEEMANN idler in original position as shown.



7. Remove the water pump pulley.



8. Install the KLEEMANN water pump pulley.



9. Use OE tool 112 589 00 40 00 to isolate the crank pulley. Remove the OE bolt.



10. Remove OE crank pulley. Do not pry against the front cover with any tools! Rock the pulley back and forth with your hands while pulling straight out. Only hand pressure is required!



11. Install KLEEMANN crank pulley using OE holding tool. Torque crank bolt to 300nm or 210 lbs/ft.

12. Install the accessory belt, radiator cooling fan and check that the belt is properly routed.

13. Remove the engine ECU and send it to KLEEMANN for programming.